




SCAN ME!

PARENTAL CONSENT REQUIRED BEFORE GOING ONLINE.

8+




# TURBO TRICK PLANES INSTRUCTIONS

**WARNING:** DO NOT AIM AT EYES OR FACE. DO NOT LAUNCH AT CLOSE RANGE. PROTECTIVE EYEWEAR ADVISED FOR PLAYERS AND OTHERS IN RANGE.




## Contents

- 1. Left rail
- 2. Right rail
- 3. Bow arms
- 4. Handle plate
- 5. Handle
- 6. Tool
- 7. Nose clip
- 8. Clamp
- 9. Screw x3
- 10. Power bands x3
- 11. Paper sheets x5 plane design




## PLANE LAUNCHER

- 1. Insert 3 screws into the right rail and connect with left rail. Do not over-tighten.




- 2. Attach the Bow arms to the Handle plate.




- 3. Attach the handle to the Handle plate.


- 4. Attach Rail to Handle plate.




- 5. Choose desired power band and attach to the hooks on the front of the launcher.




- 6. The unused bands can be stored on either side of the rail.




- 7. Make 1 of the 5 paper planes. Refer to the paper plane instruction page. Different planes perform better with different power bands. Experiment to find the best combinations!




- 8. Place the soft nose clip on the front of the plane.




- 9. Lock the nose clip in place using the clamp.




- 10. Hook the nose clip onto the middle of the power band.



- 11. Holding the back of the plane, pull back to desired power.



- 12. Launch it!



- 13. Try adjusting the flaps to change flying behavior.

Scan the QR code on the product to watch Mark explain all the science behind the action!

PARENTAL CONSENT REQUIRED BEFORE GOING ONLINE.

**WARNING:** DO NOT DISCHARGE ANY OBJECT OTHER THAN THOSE PROVIDED WITH THIS TOY. ALWAYS ATTACH THE CLIP SECURELY TO THE PAPER PLANE BEFORE LAUNCHING. NEVER ATTEMPT TO LAUNCH THE CLIP BY ITSELF.

**CAUTION:** DO NOT LAUNCH PROJECTILE AT PEOPLE OR ANIMALS!

**IMPORTANT:** RETAIN PACKAGING DETAILS FOR FUTURE REFERENCE. COLORS AND CONTENTS MAY VARY. USE ONLY THE INCLUDED TOOL FOR ASSEMBLY. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

FOR SUPPORT INFORMATION SCAN ME!



PARENTAL CONSENT REQUIRED BEFORE GOING ONLINE.



www.mossetoys.com ©2025 The Moose Group