



SCAN ME!

PARENTAL CONSENT REQUIRED
BEFORE GOING ONLINE.

8+




TURBO TRICK PLANES INSTRUCTIONS

WARNING: DO NOT AIM AT EYES OR FACE.
DO NOT LAUNCH AT CLOSE RANGE.
PROTECTIVE EYEWEAR ADVISED FOR PLAYERS AND OTHERS IN RANGE.




Contents

1. Left rail
2. Right rail
3. Bow arms
4. Handle plate
5. Handle
6. Tool
7. Nose clip
8. Clamp
9. Screw x3
10. Power bands x3
11. Paper sheets x5 plane design




PLANE LAUNCHER

- 1 Insert 3 screws into the right rail and connect with left rail.
Do not over-tighten.




- 2 Attach the Bow arms to the Handle plate.





- 3 Attach the handle to the Handle plate.


- 4 Attach Rail to Handle plate.




- 5 Choose desired power band and attach to the hooks on the front of the launcher.




- 6 The unused bands can be stored on either side of the rail.




- 7 Make 1 of the 5 paper planes. Refer to the paper plane instruction page.
Different planes perform better with different power bands. Experiment to find the best combinations!




- 8 Place the soft nose clip on the front of the plane.




- 9 Lock the nose clip in place using the clamp.




- 10 Hook the nose clip onto the middle of the power band.




- 11 Holding the back of the plane, pull back to desired power.



- 12 Launch it!



- 13 Try adjusting the flaps to change flying behavior.



Scan the QR code on
the product to watch
Mark explain all the
science behind the action!

PARENTAL CONSENT REQUIRED BEFORE GOING ONLINE.

WARNING: DO NOT DISCHARGE ANY OBJECT OTHER THAN
THOSE PROVIDED WITH THIS TOY. ALWAYS ATTACH THE CLIP
SECURELY TO THE PAPER PLANE BEFORE LAUNCHING. NEVER
ATTEMPT TO LAUNCH THE CLIP BY ITSELF.

CAUTION: DO NOT LAUNCH PROJECTILE AT PEOPLE OR
ANIMALS!

IMPORTANT: RETAIN PACKAGING DETAILS FOR FUTURE
REFERENCE. COLORS AND CONTENTS MAY VARY. USE ONLY THE
INCLUDED TOOL FOR ASSEMBLY. RETAIN INSTRUCTIONS FOR
FUTURE REFERENCE.

FOR SUPPORT INFORMATION SCAN ME!




PARENTAL CONSENT REQUIRED
BEFORE GOING ONLINE.



www.mosetoys.com
©2025 The Moose Group




TURBO TRICK PLANES




WORLD'S MOST ACCURATE
PAPER AIRPLANE

IN MARK'S "WORLD'S MOST ACCURATE PAPER AIRPLANE" VIDEO, HE FIRES A HUGE PAPER AIRPLANE THROUGH A RING OF FIRE. TO MAKE THE AIRPLANE AS ACCURATE AS POSSIBLE, HE CAREFULLY TWEAKS FOLDS AND ANGLES TO ENHANCE ITS PERFORMANCE.




ELASTIC POTENTIAL ENERGY
THE LAUNCHER'S ELASTIC BAND STORES ELASTIC POTENTIAL ENERGY WHEN YOU PULL IT BACK. THE FARTHER YOU STRETCH IT, THE MORE ENERGY IS STORED. WHEN YOU RELEASE THE BAND, THAT STORED ENERGY TURNS INTO KINETIC ENERGY, GIVING THE PLANE A BURST OF FORWARD SPEED. SELECTING A STRONGER BAND ENABLES YOU TO STORE MORE ENERGY DURING THE PULLBACK, FIRING YOUR PLANE WITH MORE POWER!



LIFT

LIFT IS THE FORCE THAT KEEPS AIRPLANES IN THE SKY! AIRPLANE WINGS ARE DESIGNED SO THAT THE AIR FLOWING OVER THE TOP OF THE WING LOWERS THE PRESSURE ON THAT SIDE, CAUSING THE WING TO BE FORCED UPWARDS. AIRPLANE WINGS ONLY GENERATE LIFT WHEN THEY ARE TRAVELING FORWARD, WHICH IS WHY YOUR PLANE NEEDS AN ENGINE, PROPELLER, OR POWER BAND.



CRUNCHLABS OFFICIAL BLUEPRINT

REVISION: 1.0

MAT'L: ABS/PP


TURBO TRICK PLANES



SCAN ME!

PARENTAL CONSENT REQUIRED
BEFORE GOING ONLINE.

8+



TURBO TRICK LAUNCHER INSTRUCTIONS

WARNING: DO NOT AIM AT EYES OR FACE.
DO NOT LAUNCH AT CLOSE RANGE.
PROTECTIVE EYEWEAR ADVISED FOR PLAYERS AND OTHERS IN RANGE.



Replace with:
FSC Logo
Label Title
License Code
Do Not Scale



www.moosetoys.com


©2025 The Moose Group




SCAN ME!

PARENTAL CONSENT REQUIRED
BEFORE GOING ONLINE.


Yellow Plane Dart




Orange Plane Stunt




Red
Plane
Trick





Green
Plane
Drift



Blue
Plane
Dart








CRUNCHLABS

CRUNCHLABS

CRUNCH
LABS


CRUNCHLABS

CRUNCHLABS




 CRUNCHLABS

 CRUNCHLABS




CRUNCH
LABS






 CRUNCHLABS

 CRUNCHLABS




CRUNCH
LABS





CRUNCHLABS

CRUNCHLABS